

ADAPTING PLASTIC DUCT TO OTHER DUCT MATERIALS

- b. Saw a 10 ft. section in half, place 5 ft. section over cable and strap or tape the two sections together. Locate straps or tape about 1 ft. from ends of 5 ft. length (See Figure 4 and Figure 5).

Figure 4






Figure 5




- c. Place another 10 ft. split duct section over the open half of the bottom section. Butt ends tightly together (See Figure 6).

Figure 6



- d. Using 2 inch wide sealing tape, put two wraps around the butted joint.
 e. Secure a strap about 1 ft. beyond the butted joint (See Figure 7).

Figure 7



APPROVED:
Richard J. Baker
 CHIEF, CONDUIT DIVISION
Khaliq Zaid
 DIRECTOR, DEPARTMENT OF TRANSPORTATION

CITY OF BALTIMORE
 DEPARTMENT OF TRANSPORTATION
 CONDUIT DIVISION

**ADAPTING PLASTIC DUCT
 TO OTHER DUCT MATERIALS**

ISSUED	REVISED	REVISED
8 / 2010		

STANDARD NO. BC 892.01-4	
SCALE: NONE	SHEET 4 OF 10